


eurotech ASSEMBLY INSTRUCTION

Remove all items from the carton . Verify all pieces before assembly.


PART LIST

KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	7	1	Backrest	13	2	Arm Bracket
2	1	Base	8	1	Backrest Post	14	1	Backrest Post Bellow
3	1	Seat Post	9	1	Backrest Screw	15	2	Armrest
4	1	Seat Post Cover	10	1	M5 Size Allen Wrench	16	2	Arm Width Adjustment Knob + Washers
5	1	Mechanism	11	1	Backrest Bolt + Washers			
6	1	Seat	12	1	M6 Size Allen Wrench			


STEP 1.





STEP 2.



STEP 3.



STEP 4.



- A Pneumatic seat height adjustment
- B Seat tilt adjustment
- C Backrest tilt adjustment
- D Seat free floating control (when B up)
- E Tilt tension adjustment knob

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
- DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER.
- DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
- DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
- DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TIGHT. AT LEAST EVERY SIX MONTHS, CHECK ALL BOLTS, SCREWS AND KNOBS TO BE SURE THEY ARE TIGHT.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.
- DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING - IT MAY CAUSE SUFFOCATION.
- FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.