PLUS

Assembly and Setup Manual

This manual explains how to assemble and set up the Network Board Series (hereinafter referred to as "this device" or "the main unit".)

Dear Customer

The installation of this device requires specialized skills. Please do not attempt to assemble this device yourself under any circumstances.

Dear Distributor/Installation Contractor

When installing this device, please take ample care to ensure that both the device and its mounting brackets can withstand any loads they are subjected to. A Phillips #2 screwdriver is necessary for installation, so please prepare it.

Please Read in the Interest of Safety

Warning

 Only the assembly/installation contractor should install this device. • Installation and assembly must be performed in accordance with this

manual. Incorrect installation or assembly could result in injury.

- Lift the main unit with 2 or more people when installing or removing. Also, make sure to lock the stand casters before installing and removing the main unit. Failure to lock the casters may lead to the stand sliding and result in an unforeseen accident.
- When installing on a wall surface, please purchase the optional wall
- The AC adapter box is where the AC power adapter for the main unit and printer is stored. The AC power adapter and power cord heat up upon use, therefore please store them correctly in accordance with "Safety Precautions" of the main unit's instruction manual.

• If a printer is used, please use the Velcro to secure this device and pre-

Remove the printer when moving this device. It may fall and cause



- * The Velcro is to prevent sliding, not to secure the printer.
- * Velcro is a registered trademark of Velcro Corporation

damage or injury.

The printer shown in this manual is a concept illustration only.

Please refer to the manual of the actual printer to be used regarding names/positions of connection ports and how to use.


vent it from sliding due to printer vibration.

List of packaged items


Main unit package

Refer to the User's Manual of the main unit. Included items vary depending on the


■ Stand package (optional item)




Network Board Series Printer tray package (optional item)




Installing the Stand (option)



2 Lock the stand casters.



3 Attach the horizontal bar to the stand legs.




4 Attach the main unit to the stand legs, and secure it with the locking knobs.




 ↑ Take care not to drop Please install the main unit on the stand with 2 or more people.


↑ Take care not to trap fingers




5 Mount the stabilizers.




Remove the 3 pieces of tape (4 pieces for the wide type) attached to the screws for installing the pen tray at the bottom of the main unit.




7 Connect the screw holes on the pen tray to the screws for installing the pen tray.



8 Slide the pen tray in the direction of the arrow.



Tighten the screws for attaching the pen tray (3 places) (4 places for the wide type).



Installing the Printer Tray (option)

Remove the grom-


met attached to

the screw hole.


1 Attach the printer tray to the horizontal bar. (1) Place the printer tray on the stand (2) Secure using the printer tray in the direction shown in the figure Hexagonal socket screws with washer

2 Sandwich the Velcro between the printer and the printer tray and check that it makes contact with the bottom of the printer.

(Back)




3 Attach the Velcro to prevent the printer falling.




Connecting the Cables

■ If a printer tray is not used DC 12V Velcro (25 x 80 mm)

■ If using the printer tray





operable may differ from the ones shown in the wiring diagram (they may be of the built-in or mounted-on type).