



**Zebra® P630i/P640i**  
Card Printer

**User Guide**



© 2004 ZIH Corp.

The copyrights in this guide and the printers described therein are owned by Zebra Technologies Corporation. Unauthorized reproduction of this manual or the software in the label print engine may result in imprisonment of up to one year and fines of up to \$10,000 (17 U.S.C.506). Copyright violators may be subject to civil liability.

Printer Software © ZIH Corp. All rights reserved worldwide.

Windows is a registered trademark of Microsoft Corporation. All other brand names, product names, or trademarks belong to their respective holders.

**Customer Order # 980541-001**

**Manufacturer Part # 980541-001 Rev. 1**

### Caution labels on P630i and P640i Printers



**Pinch Hazard** • Keep fingers away from printer cover hinges and back of cleaning cassette



**Hot surfaces** • Danger of skin burns near laminator components

### Advisories used in this Guide



**Special attention** • Advises you of important information



**Critical information** • Failure to follow instructions to the letter can cause malfunction, damage to the printer, or personal injury.



## P630i/P640i USER GUIDE

### Part 1

Section 1	<b>Introduction</b>
Section 2	<b>Media Handling</b>
Section 3	<b>Troubleshooting</b>



The separate Quick Start Guide shows how to set up the printer using the standard USB interface. If your printer was configured for the optional Parallel or Ethernet connections, refer to Tech Note TN9 in Part 2 of this Guide for instructions on driver installation.

***Aside from card lamination capability, the P630i and P640i printers are similar. The P630i laminates only the front (upper) side of the card, the P640i laminates both sides. In this Guide “P640i” means both printer models, unless otherwise noted.***

## **WARRANTY INFORMATION**

### ***Printers***

All Zebra Card Printers are warranted against defects in material or workmanship for twelve (12) months from the purchase date.

Proof of purchase or shipment date is required to validate the warranty period. The warranty becomes void if the equipment is modified, improperly installed or used, damaged by accident or neglect, or if any parts are improperly installed or replaced by the user.

*Note: Products must be packaged in the original or comparable packaging and shipping container. In the event equipment is not so packaged, or if shipping damage is evident, it will not be accepted for service under warranty. Surface transportation charges for return to customers in the continental United States is paid by Zebra. Otherwise, Zebra pays CPT (carriage paid to) nearest airport, customer pays customs, duties, taxes and freight from airport to destination. If Zebra determines that the product returned for warranty service or replacement is not defective as herein defined, the customer will pay all handling and transportation costs.*

### ***Printheads***

Since printhead wear is part of normal operation, the original printhead is covered by a twelve (12) month warranty. Warranty period begins on purchase date.

To qualify for this warranty, the printhead must be returned to the factory or to an authorized service center. Customers are not required to purchase Zebra supplies (media and/or ribbons) for warranty qualification. However, if it is determined that the use of other manufacturer supplies has caused any defect in the printhead for which a warranty claim is made, the user is responsible for Zebra's labor and material charges required to repair the defect. The warranty becomes void if the printhead is physically worn or damaged; also if it is determined that failure to follow the preventative maintenance schedule listed in the User's Guide has caused defect in the thermal printhead for which warranty claim is made.

### ***Software***

Software is warranted to be free of defects in material and workmanship for 30 days from the date of purchase. In the event of notification within the warranty period of defects, Zebra will replace the defective CD or documentation.

### ***Supplies***

Supplies are warranted to be free from defect in material and workmanship for a period of six (6) months for media and twelve (12) months for ribbon from the date of shipment by Zebra. This is provided the user has complied with storage guidelines, handling, and usage of the supplies in Zebra printers.

Zebra's sole obligation under these warranties is to furnish parts and labor for the repair or possible replacement of products found to be defective in material or workmanship during the warranty period. Zebra may in its discretion issue a credit for any such defective products in such amount as it deems reasonable.

### ***Spare Parts***


All parts, maintenance kits, options kits, and accessories are warranted to be free of defects in material and workmanship for 90 days (except where otherwise denoted) from date of purchase. This warranty becomes void if the item is modified, improperly installed or used, or damaged by accident or neglect.

## **Warranty Exclusions and Conditions**

The warranties provided above are the only warranties applicable. No other warranties, expressed or implied, are given. Zebra does not make any IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE in connection with its sale of products or services. While Zebra's desire is to be responsive to specific needs and questions, Zebra does not assume responsibility for any specific application to which any products are applied including, but not limited to, compatibility with other equipment. All statements, technical information or recommendations relating to Zebra products are based upon tests believed to be reliable yet do not constitute a guaranty or warranty.

Zebra's maximum liability for warranty claims is limited to the invoice price of the product claimed defective. Zebra does

## AGENCY APPROVALS



### Product Disposal

Do not dispose of this product in unsorted municipal waste. This product is recyclable. Please recycle according to your local standards. For more information, please see our web site at: <http://www.zebra.com/recycle>

## CONTACT INFORMATION

### Zebra Technologies • Card Printer Solutions

[www.zebracard.com](http://www.zebracard.com)

#### *North America*

1001 Flynn Road  
Camarillo, CA 93012-8706 USA  
Telephone: +1(805) 579 1800  
Fax: +1(805) 579 1808  
Toll free in the US: 800 452 4056  
e-mail: [cards@zebra.com](mailto:cards@zebra.com)

#### *Europe, Middle East and Africa*

The Valley Centre, Gordon Road  
High Wycombe  
Buckinghamshire HP13 6EQ, UK  
Telephone: +44 870 241 1527  
Fax: +44 870 241 0765  
e-mail: [eurosales@zebra.com](mailto:eurosales@zebra.com)

#### *Asia Pacific*

16 New Industrial Road  
#05-03 Hudson TechnoCentre  
Singapore 536204  
Telephone: +65 6858 0722  
Fax: +65 6885 0836  
e-mail: [asiasales@zebra.com](mailto:asiasales@zebra.com)

#### *Latin America*

9800 NW 41st Street, Suite 220  
Doral, FL 33178  
Telephone: +1(305) 558 3100  
Fax: +1(805) 558 8485  
e-mail: [latinsales@zebra.com](mailto:latinsales@zebra.com)